Truss Analysis



Review: Member Design

 Compression elements have lower stresses due to buckling

$$\mathbf{P_{cr}} = \pi^2 \mathbf{EI} / (\mathbf{kL})^2$$

• When using graphic statics for truss analysis, use clockwise convention to determine if an element is in tension or compression.

Truss Lecture


- Moments of forces for finding reactions
- Method of joints for analyzing trusses

Graphical analysis for analyzing trusses


Three Equations of Equilibrium

- **1.** Sum of vertical forces must be zero $\Sigma \mathbf{F}_{y} = \mathbf{0}$
- 2. Sum of horizontal forces must be zero $\Sigma \mathbf{F}_{\mathbf{x}} = \mathbf{0}$
- 3. Sum of moments must be zero $\Sigma M = 0$

Moment Equilibrium




Moment of Force




M = Fa


Moment Equilibrium




Crane Counterweight



Equilibrium of Ski Lift Tower



Eiffel Tower




opyright 2002 keith@opifice.com


Cantilevered Streetlight



Weight of Lamp




Reactions at Supports



Trusses

Rotational Equilibrium

- Sum of the moments must equal zero.
- Use to calculate reactions at supports and to find internal forces



• Look for examples of moment equilibrium around you

